

Non Skid

Masking Pattern

- Mark pattern with pencil
- Lay first layer of tape $\frac{1}{4}$ inch from pencil line
- Lay second layer of tape on line
- Using masking paper on 1st layer of tape only
- Pull second layer of tape immediately after spraying
- Remove balance of masking after nonskid has “gone off”

(Quantities are as used on the Swim Grid)

1st Coat (Undercoat)

- 600 CC Roberts Gray (not mixed with white), **NO WAX.**
- 3% catalyst (hot mix)
- Roberts Gray (not mixed with white)
- Roll on (thin coat).

2nd Coat (Non Skid)

- Make 50/50 mix 500cc cloud white and 500cc roberts gray = 1000cc (1 liter)
- **AD WAX**
- 1 real cup of cabosel
- 1.5% catalyst (slower mix)
- Mix to a smooth consistency

Spraying

- At 65 PSI, spray from above with Schutz Undercoating Gun
- Maintain spray angle – the more vertical the better
- Stay 1 meter from work (the further away the more it “spatters”)